

# HAPILIN®

ELECTRIC  
FOOT **SCRUBBER**



[www.hapilin.com](http://www.hapilin.com)

# HAPILIN®

ELECTRIC  
FOOT **SCRUBBER**




[www.hapilin.com](http://www.hapilin.com)


## جهاز تقشير القدم

جهاز تقشير القدم سيمنحك فرصة للتخلص من كل التشققات والخشونة والقشور، حيث يتميز برأس تقشير من الكربون يدور في 360°، والذي بدوره يعمل على تقشير لطيف للتخلص من خلايا الجلد الميتة، والجلد السميك والصلب، وتشققات الجلد، والقشور.. إلخ.

بالإضافة إلى أنه يسمح لك باختيار السرعة المناسبة للتقشير من سرعتين حسب حالة جلدك، ف خيار السرعة المنخفضة يعمل على تنظيف الجلد وإزالة القشور بلطف من قدميك، أما السرعة العالية فتقشر الجلد بعمق للتخلص من جميع الشقوق.



- ① غطاء الجهاز
- ② رأس دوار من الكربون
- ③ زر فك وتركيب رأس الكربون
- ④ زر التحكم في السرعة
- ⑤ زر (تشغيل/إطفاء)
- ⑥ غرفة البطارية



# ELECTRIC FOOT SCRUBBER

## المواصفات:

اسم المنتج: Hapilin® Electric Foot Scrubber

رقم الموديل: HA-1638

الجهد: 6 فولت

القوة: 3.6 وات

التيار: 0.6 أمبير

أقل سرعة: 200±1100 RPM

أقصى سرعة: 200±1300 RPM

## الملحقات:

- رأس دوار من الكربون
- غطاء حماية
- رأسان تقشير إضافيان

## الخصائص:

### رأس التقشير من الكربون:

لما يتميز به من المسامية التي تناسب تقشير الجلد القاسي، وسطح يحتك بالجلد ويقوم بتعييمه برفق دون جرحه.

### سهولة الفك والتركيب:

لتنظيف أسهل لرأس الكربون.

### تصميم انسيابي خفيف الوزن:

الجهاز مصمم بانحاء ليسهل حمله في قبضة اليد، حتى يعطيك أقصى راحة وكفاءة وأمان أثناء الاستخدام.

### سرعتان للتقشير:

حتى يسمح لك باختيار مستوى سرعة الدوران لتقشير الجلد حسب حالته. حيث أن خيار السرعة المنخفضة يعمل على تنظيف الجلد وإزالة الأوساخ والقشور بلطف من قدميك، أما السرعة العالية فتقشر الجلد بعمق للتخلص من جميع الشقوق والقشور.

## خطوات التشغيل:

### 1- تركيب البطارية:

- قومي بفتح غرفة البطارية بسحب الغطاء للخارج.
- قومي بتثبيت 4 بطاريات من نوع AA.
- أعيدي الغطاء بشكل صحيح عن طريق الضغط عليه لأسفل وإبقائه في مكانه (سيصدر صوت نقرة عند التثبيت بشكل صحيح).



### 2- قومي بالضغط على زر (تشغيل/إيقاف).



- ### 3- قومي باختيار مستوى التقيشير بالضغط على زر السرعة لتحديد السرعة المطلوبة إما عالية أو منخفضة.



# ELECTRIC FOOT SCRUBBER

## طريقة الاستخدام:

1- قبل الاستخدام، قومي بتدوير رأس الكربون ببطء حتى تتأكدي من تثبيته تماماً.



2- قومي بوضع قدميك في ماء دافئ لمدة 10 دقائق، ثم جففيهما بمنشفة.

**ملحوظة:** تأكدي من ترطيب قدميك قبل استخدام الجهاز.



3- قومي بتشغيل الجهاز ثم حركيه بلطف لإزالة التشققات.



4- راقبي بعناية لمعرفة ما إذا تم إزالة الجلد الميت أم لا، واحذري الإفراط في الاستخدام الذي قد يؤذي قدميك.



5- بعد الانتهاء من الاستخدام، قومي بالضغط على زر (تشغيل/إطفاء).



6- اشطفي قدميك جيداً بالماء بعد الاستخدام، ثم رطبيها بمرطب مناسب للقدم.



## خطوات التنظيف:

بعد الاستخدام، قومي بفصل رأس الكربون الدوّار من الجهاز ثم قومي بشطفها جيداً بالماء، ثم اتركيه ليجف.

## فك وتركيب الرأس الدوّار:

اضغطي على زر الفك والتركيب (بجانب الرأس الدوّار)، ثم قومي بفك أو تركيب الرأس بلطف.

## تعليمات السلامة:

- لا يستخدم الجهاز من قبل مرضى السكر.
- لا تستخدم الجهاز عندما يوجد بالقدمين أي جرح أو التهاب خطير أو أي أمراض جلدية أخرى.
- لا تفرط في استخدام الجهاز على نفس المنطقة لفترة طويلة.
- لا تترك الجهاز غير ملاحظ أثناء التشغيل.
- احرصي دائماً على تنظيف الجهاز بعد كل استخدام.
- لا تعرضي الجهاز داخل الماء.
- لا يحفظ الجهاز في درجات الحرارة العالية.
- يحفظ الجهاز بعيداً عن متناول الأطفال.

## خطاب الضمان:

الجهاز حاصل على شهادات CE ، RoHS ، المطابقة للأمان والسلامة الأوروبية، ومصنع طبقاً لمعايير الجودة الأمريكية، ويأتي مع ضمان استرجاع لمدة 14 يوماً وذلك من تاريخ الاستلام المثبت على الفاتورة، وتمتد إلى 30 يوماً في حالة وجود عيب تصنيع، ويأتي أيضاً مع ضمان صيانة لمدة عامين.

في حالة توقف عمل الجهاز الخاص بك في غضون أول عامين من الشراء، يرجى التواصل معنا عن طريق البريد الإلكتروني [warranty@hapilin.com](mailto:warranty@hapilin.com) موضحاً المشكلة وسيتهم عمل اللازم حرصاً على إرضائك.

### الضمان المقدم يغطي عيوب التصنيع فقط ولا ينطبق على الحالات التالية:

- الإهمال وسوء استخدام المنتج.
- كسر الجهاز.
- تعريض الجهاز للماء.
- الأضرار الناجمة عن محاولة إصلاح الجهاز من قبل طرف غير مصرح به.

### تنبيه:

- الضمان لا يشمل رؤوس الكربون لأنها ضمن الأجزاء الاستهلاكية.
- ضمان الاسترجاع لا يسري في حالة الاستخدام الشخصي للجهاز.

يتم الكشف عن الجهاز قبل الشحن ونتيجة لذلك، أي ضرر أو خدش يحدث على الغلاف الخارجي لا يغطيه الضمان.

تتحمل الشركة كافة التكاليف لإصلاح/استبدال الجهاز الخاص بك في حالة حدوث عيب تصنيع بالإضافة إلى تكاليف الشحن، ويتحمل العميل تكلفة الشحن في حالة عدم وجود أي عيب تصنيع.

يجب إرسال الجهاز في العبوة الأصلية مع وصل الشراء عن طريق شركة الشحن، ويمكن تتبعها.

برجاء الحفاظ على هذا الضمان مع الجهاز الخاص بك بحيث يكون في متناول يديك في حالة مواجهة أي مشكلة.

## Letter of Guarantee:

This appliance is RoHS and CE compliant with the health, safety, and environmental protection standards of the European Economic Area. It also complies with the American Quality and Safety Standards.

It comes with a 14-day money-back guarantee which starts from the day of invoice on the receipt. It can extend to 30 days in the case of a manufacturing defect. It also comes with a 2-year repair warranty.

In the event your appliance stops working within the first 2 years of purchase, please contact us by sending an email to [warranty@hapilin.com](mailto:warranty@hapilin.com) explaining the problem clearly. We will then be happy to advise you on what to do to ensure your satisfaction.

**The warranty applies to manufacturing defects only and does not apply to the following cases:**

- Negligence and product misuse.
- Breaking or cracking the appliance.
- Exposing the appliance to water.
- Damage caused by an attempt to repair the appliance by an unauthorized party

### **Important:**

- This guarantee does not include the carborundum heads which is a consumable part.
- The money-back guarantee is not applied in the case of personal use of the product.

The appliance has been inspected prior to shipment, so any damage or crack occurring to the outer casing is not covered by this warranty.

As a company, we will be responsible for any costs incurred for repair/replacement of your appliance in the event of a manufacturing fault, in addition to the return shipping costs. However, you will be responsible for shipping costs for the return of the original appliance, if the fault is not a manufacturing one, which must be sent back using a trackable/traceable delivery service, returned in its original box with the original purchase receipt.

**Please keep this warranty document with your appliance so that it is handy in the event a problem arises.**



5. Turn off the appliance.



6. Clean your feet with water, then moisturize them with lotion or foot cream.



## Cleaning:

After using the appliance, take off the roller head. Carefully rinse it the roller with water only and keep it dry.

## Roller head removal and installation:

Simply press on the button with an up-arrow at the side of the roller head. Then, gently remove or install the roller head.

## Safety Matters:

- Diabetics cannot use this appliance.
- Do not use it when your foot is damaged or if you have serious dermatitis or chapped feet.
- Do not overuse the appliance in the same area for too long.
- Do not leave the appliance unattended while it is switched on.
- Keep the device dry and clean.
- Keep away from water.
- Keep away from high temperature.
- Keep out of the reach of children.

## Usage Instructions:

1. Before use, slightly roll the roller head with your finger to make sure it is safely installed.



2. Wet your feet with warm water for 10 minutes and then dry your feet with a towel.

**Note:** Make sure your feet are moist before using the appliance.



3. Start moving the appliance on the bottom of your feet to remove the callus.



4. Watch carefully to see if the callus is properly removed. Do not overuse the appliance to avoid any harm that could be caused to your feet.



## Operating Instructions:

### 1. Battery installation:

- Open the battery chamber by pulling it outwards.
- Install 4 AA batteries.
- Return the cover properly by pressing it downwards till it clicks to make sure that it is in place.



### 2. Press the ON/OFF button to switch the device on.



### 3. Press the speed button to select the desired speed out of two speeds either high or low.



## Specifications:

**Product Name:** Hapilin® Electric Foot Scrubber

**Model No.** HA-1638

**Rated Voltage:** 6V

**Rated Power:** 3.6W

**Rated Current:** 0.6A

**Low Speed:** 1100±200rpm

**High Speed:** 1300±200rpm

## Accessories:

- Carborundum roller head
- Protective cover
- 2 Extra roller heads

## Product Features:

### **The Carborundum substance:**

The head is made of abrasive material for perfect scraping of hard heels with no harm.

### **Removable carborundum roller head:**

Easily detachable to make it easier to clean and change.

### **Streamlined handle:**

Ergonomically curved to fit comfortably in your hand to give you maximum comfort and efficiency.

### **Two available speeds:**

It allows you to choose the level of exfoliation. The low-speed option will cleanse and remove dirt and grime from your skin while gently exfoliating the crusty layer on your feet. The high speed deeply exfoliates the skin and gets rid of all cracks and crusts.

## Hapilin® Electric Foot Scrubber

Hapilin® Electric Foot Scrubber gives you the chance to get rid of all debris, crustiness, flakiness and accumulation. Our Electric Foot Scrubber offers flawless exfoliation for crusty rough heels with its carborundum material. It spins in a 360° motion to remove all callus and cutin and to get rid of dead, rough, cracked, and split skin. It has two speed levels: one provides fine scrubbing and the other provides rough scrubbing to fulfill all your different needs.

- ① Protective Cover
- ② Carborundum Roller Head
- ③ Roller Head Installation Place
- ④ Speed Button
- ⑤ ON/OFF Button
- ⑥ Battery Chamber

